



Embassy Flute
No. 3794 ■
4½ oz./13.3 cl./133 ml.
H7¾ T1¼ B2¾ D2¾
1 doz./5# • .42 cu.ft.
SCC 574636



Teardrop Flute
No. 3996 ■
5¾ oz./17.0 cl./170 ml.
H7¾ T2 B2¾ D2¾
1 doz./6# • .53 cu.ft.
SCC 574667



Embassy Flute
No. 3795 ■
6 oz./17.7 cl./177 ml.
H8½ T2 B2¾ D2¾
1 doz./6# • .55 cu.ft.
SCC 574643



Perception Flute
No. 3096 ■
5¾ oz./17.0 cl./170 ml.
H8½ T1¾ B2¾ D2¾
1 doz./6# • .57 cu.ft.
SCC 252340



Charisma Tall Flute
No. 4196SR ■
6 oz./17.7 cl./177 ml.
H8¾ T2 B2¾ D2¾
2 doz./12# • 1.16 cu.ft.
SCC 878390

Also available
with
©Fizzazz®
—see p.44



**Embassy Royale
Tall Flute**
No. 3796 ■
6 oz./17.7 cl./177 ml.
H8¾ T2 B2¾ D2¾
1 doz./6# • .59 cu.ft.
SCC 574650



**Citation Gourmet
Tulip Champagne**
No. 8477 ●
6 oz./17.7 cl./177 ml.
H7¾ T2½ B2¾ D2¾
1 doz./5# • .61 cu.ft.
SCC 632022



**Citation Gourmet
Tulip Champagne**
No. 8476 ●
9 oz./26.6 cl./266 ml.
H8½ T2¼ B2¾ D2¾
1 doz./6# • .66 cu.ft.
SCC 573844



TABLETOPTIP

To prevent excessive loss of carbonation before drinking, champagne should be carefully poured down the side of the flute, rather than straight into the glass.